



DISH DETERGENT

CONCENTRATED DETERGENT FOR MANUAL WAREWASHING

Dish Detergent (DD) is a concentrated, environmentally-friendly detergent for manually washing pots, pans, utensils, glassware and dishware. DD pulls heavy grease off pots and pans yet is gentle on hands. DD provides long-lasting suds and works in both hard and soft water.

Physical Properties (Typical)

Appearance	Purple Liquid
Density	8.4 pounds/gallon
Odor	Characteristic
pH	8.0
Specific Gravity	1.01 (Water = 1.00)



Directions for Use

Usage

Use 1-2 oz (29.6-59.1 ml) DD per 4 gal (15.1 L) of water in sink.

Note: DISH DETERGENT will work in any temperature liquid water. Warm (90F - 110F, 32C - 43C) water will wash more quickly than cold.

Manual Washing Procedures

Remove large food particles prior to washing, immerse dishware in sink and allow to soak for 2 to 3 minutes to penetrate heavy soils, rinse. Soak longer if cold water is used.

Three-compartment Sink Procedures

Wash dishware in 1st sink, rinse with clean water in 2nd sink, sanitize with QDII Sanitizer in 3rd sink, let air dry.

All significant components in Dish Detergent are biodegradable. A biodegradability statement is available upon request.

Dish Detergent does not contain any nonylphenol ethoxylates (NPEs) and therefore is better for the environment and faces fewer regulatory restrictions and environmental implications than similar NPE-containing products.

Dish Detergent does not contain any phosphates.

Available sizes: 1 gal., 5 gal. & 55 gal.

Complete Cleaning Solutions

DeVere Company, Inc. • 1923 Beloit Ave. • Janesville, WI 53546 U.S.A.
DeVereChemical.com • 1-608-752-0576 • 1-800-833-8373